

**UBERBIKE**

No.	Description	Q'ty
1	BB Bearing	2
2-1	2mm Spacer	1
2-2	2.5mm Spacer	2
3	1mm Spacer	1

**WARNING**

➔ Only apply pressure to bearing outer race when installing to prevent bearing damage!

MTB-92mm: 1mm spacer \*1  
 MTB-89.5mm: 1mm spacer \*1  
 Road-86.5mm: No spacer

